

Turnover Ball Model Chart

KIT NUMBER		MOUNTING BOX	CENTER BOX	
GNRK	# OF BOXES FOR KIT	GNRM	GNRC	PICKUP TRUCK YEAR, MAKE AND MODEL
CHEVY/GMC		CHEVY/GMC		CHEVY/GMC
1000	CONSISTS OF 2 BOXES	1000R	800R	1988-1998 Chevrolet & GMC 1/2, 3/4, & 1 Ton Long Bed Trucks and fits 1999-2000 Chevrolet & GMC 3/4 & 1 Ton Heavy Duty Long Bed Trucks - Old Body Style
1050	CONSISTS OF 2 BOXES	1050R	950R	1988-1998 Chevrolet & GMC 1/2, 3/4, & 1 Ton Short Bed Trucks and fits 1999-2000 Chevrolet & GMC 3/4 & 1 Ton Short Bed Trucks - Old Body Style
1059	CONSISTS OF 2 BOXES	1059R	959R	1999-2006 Chevrolet & GMC 1/2 & 3/4 Ton Light Duty Short & Long Bed Trucks - New Body
1061	CONSISTS OF 2 BOXES	1061R	959R	2001-2006 Chevrolet & GMC 3/4 Ton Heavy Duty Short & Long Bed Trucks - New Body
1062	CONSISTS OF 2 BOXES	1062R	962R	2001-2006 Chevrolet & GMC 1 Ton Heavy Duty Truck - New Body
1400	CONSISTS OF 1 BOX	1400R	N/A	1973-1987 Chevrolet & GMC 1/2, 3/4, & 1 Ton (Requires Drilling)
FORD		FORD		FORD
1100	CONSISTS OF 2 BOXES	1100R	800R	1980-1996 Ford 3/4 & 1 Ton WITHOUT Overload Springs and fits 1997-1998 Ford 3/4 & 1 ton Trucks with the Old Body Style WITHOUT Overload Springs
1110	CONSISTS OF 2 BOXES	1110R	800R	1980-1996 Ford 3/4 & 1 Ton WITH Overload Springs (Requires Drilling 2 Holes) and fits 1997-1998 Ford 3/4 & 1 Ton Trucks W/ Overload Springs - Old Body Style (Requires Drilling 2 Holes)
1150	CONSISTS OF 2 BOXES	1150R	800R	1980-1996 Ford 1/2 Ton Trucks
1197	CONSISTS OF 2 BOXES	1197R	800R	1997-2003 Ford 1/2 & Light Duty 3/4 Ton Trucks, & 2004 Heritage Edition
1104	CONSISTS OF 2 BOXES	1104R	959R	2004-2006 Ford 1/2 Ton Trucks
1105	CONSISTS OF 2 BOXES	1105R	800R	1999-2006 Ford 3/4 & 1 Ton Super Duty with or without Aftermarket Air Bag Overloads
DODGE		DODGE		DODGE
1394	CONSISTS OF 2 BOXES	1394R	900R	1994-2001 Dodge 1/2 Ton Trucks and fits 1994-2002 Dodge 3/4 Ton & 1 Ton
1316	CONSISTS OF 2 BOXES	1316R	900R	2002-2006 Dodge 1/2 Ton Long and Short Bed (Except Mega-Cab)
1306	CONSISTS OF 2 BOXES	1306R	906R	2003-2006 Dodge 3/4 & 1 Ton Long & Short Bed (Also fits 2006 1/2, 3/4 & 1 ton Mega-Cab Short Bed)
1300	CONSISTS OF 1 BOX	1300R	N/A	1973-1993 Dodge 1/2, 3/4, & 1 Ton (Requires Drilling)
NISSAN		NISSAN		NISSAN
1204	CONSISTS OF 2 BOXES	1204R	1214R	2004-2006 Nissan Titan
TOYOTA		TOYOTA		TOYOTA
1251	CONSISTS OF 2 BOXES	1251R	1250R	2000-2006 Toyota Tundra
ACCESSORIES		ACCESSORIES		Turnover Ball Accessory Chart
1500	CONSISTS OF 1 BOX	1500R	N/A	Flatbed Kit (requires welding)
3000	CONSISTS OF 2 BOXES	RVB3006	RVC3006	Companion 5th Wheel RV Hitch kit
3050	CONSISTS OF 2 BOXES	RVB3055	RVC3006	Companion 5th Wheel RV Hitch kit for flatbeds
1900-2-1600				Safety Chain Kit
1700				Plug
1900				Latch Pin Handle
2000				Replacement Ball
2025				3" Ball
2050				Hi-Rise Ball (Rated at 20,000 lbs.)
4000				King Pin
4025				Inverted Ball
4075				Eyelet
4085				Gooseneck Extender

Form BW Part Numbers 0402006



1216 Hwy 224 / PO Box 186 / Humboldt, KS. 66748
P: 620.473.3664 / 800.248.6564 / F: 620.473.3766
email: hitches@turnoverball.com / www.turnoverball.com